
Class notes based upon Patterson & Hennessy: Book & Lecture Notes Patterson's 1997 course notes (U.C. Berkeley CS 152, 1997) Tom Fountain 2000 course notes (Stanford EE182) Michael Wahl 2000 lecture notes (U. of Siegen CS 3339) Ben Dugan 2001 lecture notes (UW-CSE 378) Professor Scott Hauck lecture notes (UW EE 471) Why are you here?

What things are important when buying a computer?

Computer "Performance"

MIPS (Million Instructions Per Second) vs. MHz (Million Cycles Per Second)

Throughput (jobs/seconds) vs. Latency (time to complete a job)



Performance Example: Planes

Airplane	Passenger Capacity	Cruising Range (miles)	Cruising Speed (mph)	Passenger Throughput (passengermile/hour)
Boeing 777	375	4630	610	228,750
Boeing 747	470	4150	610	286,700
Concorde	132	4000	1350	178,200
Douglas DC-8	146	8720	544	79,424

Which is the "best" plane?

Which gets one passenger to the destination first?


Which moves the most passengers?

Which goes the furthest?

Which is the "speediest" plane (between Seattle and NY for example)?

Latency: how fast is one person moved?

Throughput: number of people per time moved?



Example: Machine *Orange* and *Grape* run a program Orange takes 5 seconds, Grape takes 10 seconds

Execution Time

Elapsed Time

counts everything (disk and memory accesses, I/O, etc.)

a useful number, but often not good for comparison purposes

CPU time

doesn't count I/O or time spent running other programs can be broken up into system time, and user time

Example: Unix "time" command

fpga.olin.edu> time javac CircuitViewer.java
3.370u 0.570s 0:12.44 31.6%

Our focus: user CPU time

time spent executing the lines of code that are "in" our program

CPU Time

CPU execution time for a program	=	CPU clock cycles for a program	*	Clock period
CPU execution time for a program	=	CPU clock cycles for a program	*	1 Clock rate


Application example:

A program takes 10 seconds on computer *Orange*, with a 400MHz clock. Our design team is developing a machine *Grape* with a much higher clock rate, but it will require 1.2 times as many clock cycles. If we want to be able to run the program in 6 second, how fast must the clock rate be?

 $ORANGE 105 = \frac{x}{400}$

ERIC SEZ > 800 MHZ

How do the # of instructions in a program relate to the execution time?



CPI Example

Suppose we have two implementations of the same instruction set (ISA).

For some program

Machine A has a clock cycle time of 10 ns. and a CPI of 2.0 Machine B has a clock cycle time of 20 ns. and a CPI of 1.2

What machine is faster for this program, and by how much?

CPU Clock Cycles
$$f = I \times 2.0$$

CPU Clock Cycles $g = I \times 1.2$
(PUTIME = I x 2.0 x 10 AS = 20x INS
 $B = I \times 1.2 \times 200 \text{ s} = 24 \times \text{INS}$
 $\frac{24 \times \text{INS}}{20 \times \text{INS}} = 1.2 \times 1.2 \times$

Computing CPI

Different types of instructions can take very different amounts of cycles Memory accesses, integer math, floating point, control flow

$$CPI = \sum_{types} \left(Cycles_{type} * Frequency_{type} \right)$$

Instruction Type	Type Cycles	Type Frequency	Cycles * Freq
ALU	1	50%	• 5
Load	5	20%	(0)
Store	3	10%	Ø.3
Branch	2	20%	0,4
		CPI:	2.2

CPI & Processor Tradeoffs

Instruction Type	Type Cycles	Type Frequency
ALU	1	50%
Load	5	20%
Store	3	10%
Branch	2	20%

- x = 1,22×

How much faster would the machine be if:

- 1. A data cache reduced the average load time to 2 cycles? DLP = 2.2 = $1.375 \times$ NEW = 1.6
- 2. Branch prediction shaved a cycle off the branch time?
- 3. Two ALU instructions could be executed at once?

 $- = | \cdot | \times$

. 2.2

The impact of a performance improvement is limited by what is NOT improved:

Example: Assume a program runs in 100 seconds on a machine, with multiply responsible for 80 seconds of this time. How much do we have to speed up multiply to make the program run 4 times faster?

 $OLP = 1005 - 755. = 7205 + \frac{80}{N}$ N = 16.

5 times faster?

Warning 2: MIPs, MHz ≠ Performance

Higher MHz (clock rate) doesn't always mean better CPU Orange computer: 1000 MHz, CPI: 2.5, 1 billion instruction program

Grape computer: 500MHz, CPI: 1.1, 1 billion instruction program


Higher MIPs (million instructions per second) doesn't always mean better CPU
1 MHz machine, with two different compilers
Compiler A on program X: 10M ALU, 1M Load
Compiler B on program X: 5M ALU, 1M Load

Execution Time: A B	Instruction Type	Type Cycles
	ALU	1
	Load	5
	Store	3
MIPS: A B	Branch	2

Machine performance:



Better performance:



Improving performance must balance each constraint

Example: RISC vs. CISC